

## What is DVR?

DVR stands for Digital Video Recorder. It gives you complete control over your TV. Your favorite shows are always here, waiting for you, at the touch of a button on your Digital Remote.

## Basic Buttons

1. Press **POWER** to turn the TV on and off.
2. Press **VOL +** and **-** to control the volume.
3. Press **CH +** and **-** to channel surf.
4. Press **NUMBER** buttons to select any channel by number.
5. Press **MUTE** to turn off the sound.
6. Press **LAST** to bring up the last channel you watched.

## Advanced Buttons

1. Buttons in the top row let you select which device to control. Press **TV** to control your TV, or press **CBL** to control your Digital SmartBox. **IMPORTANT: You must press CBL to access your DVR features.**
2. Press **GUIDE** to display the Navigator interactive on-screen guide. You can see what's on TV on any channel, over the next seven days.
  - Press **UP/DOWN** arrows to scroll through channel listings.
  - Press the **LEFT/RIGHT** arrows to scroll through time slots.
  - Press **INFO** to get more detailed program information on any show.

- Press **SELECT** to select whatever program or option you've highlighted. Once you find a show you like, press **SELECT** to tune to it instantly. If you select a future show, you will be given the option to record it on your DVR.
- Press **EXIT** to clear the on-screen graphics and return to the show you were watching.

## Special Buttons

1. Press **LIST** to bring up a list of all the shows you've recorded, and recordings in progress. To view future recordings you've scheduled, press **B**.
2. Press **INSTANT REPLAY** to rewind 10 seconds back so you can replay what you were just watching.
3. When you've paused or rewound the program, press **LIVE** to take you to real time on the channel you're watching.
4. Press **PLAY** to play your show at normal speed. If you press it twice very quickly, you'll see your show in slow motion.
5. **FAST FORWARD/REWIND** work the same as on your VCR, but with some extra features. When you press them twice, you go faster. When you press them three times, you move at the fastest speed, letting you skip around your show very quickly.
6. Press **RECORD** to select a program to record. You can do this in two different ways – either while you're watching a program, or from the Navigator interactive on-screen guide. To learn more about recording, watch the **Recording Shows** tutorial.
7. Press **PAUSE** to freeze the program you're watching.
8. Press **STOP** to stop the program you're watching.

– continued –

— continued —

Depending on when you press it, you get certain special options:

- If you press it while you're *recording a program*, you have the option of stopping your recording.
- If you press it while watching a *previously recorded program*, you get the additional options to erase the recording, save the recording, or resume watching.

### Picture in Picture

With Picture in Picture, or PIP, you can watch two shows at once.

1. Press **ON/OFF** to turn picture in picture on or off, and change the size.
2. Press **SWAP** to swap the video in the main screen and the picture in picture window.
3. Press **MOVE** to move the picture in picture window to another location on the screen.
4. Press **CH +** and **-** to surf through channels inside the picture in picture window.