

What is the Power-On Channel

You can set your Digital SmartBox so that every time you turn it on, your TV automatically tunes to your Favorite Channel.

When your Digital SmartBox was installed, a Power-On Channel may have been set up. These instructions show you how to change it very easily to suit your needs.

Setting the Power-On Channel

1. Press **SETTINGS** on your Digital Remote to display the **Quick Settings** menu on your TV screen.
2. Press **A** to display the detailed **General Settings** menu.
3. Press the **UP** or **DOWN** arrows to find the **Power-On Channel**. Then press **SELECT**.
4. Press the **UP** or **DOWN** arrows to find the channel you want. You can also scroll faster with **PAGE+/-**.
5. Once you have found the channel you want, press **A** to accept your choice.

Choosing Last Channel

1. You can also select **Last Channel** as your **Power-On Channel**. Your TV will tune to the last channel you watched before turning off the Digital SmartBox.
2. When you are in the **Power-On Channel** option in the **General Settings** menu, scroll past the list of channels to find the choice called **Last Channel**.
3. Once you have selected **Last Channel**, press **A** to accept your choice.

How to Use the Power-On Channel

Once you have set your **Power-On Channel**, you don't have to do anything else. Now, every time you turn on your Digital SmartBox, the TV will automatically tune to your **Power-On Channel**.

Tip: The **Power-On Channel** setting works only if you turn your TV off and on using your Digital SmartBox (by pressing **CBL**).