

## Recording a Show

You can easily record shows while you're watching them or set up future shows to record. Record up to 50 hours so you never miss your favorite shows.

### Record While You're Watching

1. Any time you're watching a program, you can start recording at the touch of a button. Just press **RECORD**. Then press **SELECT** to select **Record this show** from the menu to confirm your choice.
2. You can start recording *any time* within the first hour of a show you've been watching since the beginning, and your DVR will still save the *entire* show.
3. You can repeat the process to record a second show that's on at the same time. While both of these are recording, you can watch a third *previously recorded* show.
4. At any time, to verify your show is recording, press **INFO**. **RECORD** will be displayed in the channel banner, along with show information to let you know your program is being recorded.

### Recording Future Shows

1. You can select future shows to record using the Navigator interactive on-screen guide. Press **GUIDE**.
2. Use the **UP/DOWN, LEFT/RIGHT** arrows to browse through the show listings, and time periods.
3. Once the show you want is highlighted, press **RECORD**. Then select **Record this Show**.
4. Press **SELECT** to confirm. Your program is now highlighted in red on the program guide, and is set to record.

## Recording Options

You can get more options that allow you to fine-tune your recording choices. Here are some of the most common options:

### Option 1: Extend Recording Time

**Tip:** This is great for when you're recording a sporting event that may go into overtime or an awards show that's running long.

1. After setting up a recording (see above steps), press **LIST** to view your list of chosen shows.
2. Press **B** to choose your list of Scheduled Recordings.
3. Select a show with the **UP/DOWN** arrows and press **SELECT**.
4. Use the **UP/DOWN** arrows to highlight either the **Start Time** or **End Time** option. The default option is set to record **On Time**. Use the **LEFT/RIGHT** arrows to choose the number of additional minutes before or after the event you want to record.
5. Press **A** to accept.

### Option 2: Saving Your Shows

This allows you to choose how long your recorded shows will be saved.

1. After setting up a recording (see steps above), press **LIST** to view your list of chosen shows.
2. Press **B** to display your list of Scheduled Recordings.
3. Select a show with the **UP/DOWN** arrows and press **SELECT**.
4. Use the **UP/DOWN** arrows to highlight **Save**.

— continued —

— continued —

5. Use the **LEFT/RIGHT** arrows to choose “Until space is needed” (this will save your show until more space is needed to record new shows) or “Until manually erased” (this will save your show until YOU actually erase it). “Until manually erased” is the safest option for your most important recordings.

6. Press **A** to accept.

### ***Option 3: Recording an Entire Series***

**Tip:** Use this so you don’t miss any episodes of your favorite shows.

When you first set up a recording (see above), instead of choosing **Record this Show**, use the **UP** arrow to select **Record Entire Series** and press **SELECT**. Then use **Series Manager** from the menu to give you more options on managing how you want your favorite series to be recorded.

1. Press **LIST**.

2. Press **C** for **Series Manager** to view those series you’ve chosen to record. Select a show using the **UP/DOWN** arrows and press **SELECT**.

3. You will now see the following options in the menu:

- Series Recording Priority – Sets which series take precedence if any are scheduled at the same time.
- Series Recording Options – Allows you to choose whether to record all episodes on any channel or first run episodes, which channel(s) to record from, how many episodes to keep, etc.
- Series Repeat Options – Allows you to choose which day(s) of the week to record repeat episodes.
- Cancel Series Recording – Cancels your recording

4. Use the **UP/DOWN** arrows to highlight any of these choices and press **SELECT**. Follow the on-screen instructions and press **A** to accept your choices.